











654321



ECO Frame assembly instructions

Type	Description
	The ECO Series products is intended for use by fully qualified, trained and competent persons to provide safe and secure installation and adjustment of projectors setups.
	Warning: Handling only by instructed, qualified and authorised person with a minimum age 18 years and of sound mind.
	Do not remove or replace any parts of the ECO Series products on your own. Contact the manufacturer or service partner in case of damage or loss. Removing or replacing parts by non-certified companies or people might result in serious accidents and death.
	When assembling the parts of the ECO-FRAME never apply significant force. If significant force is necessary, the cause may be a faulty part. Ignoring this, might cause significant damage to the product and serious accidents may result.
	Use only original parts such as screws, washers, nuts etc. Using other parts than the ones recommended by the manufacturer may result in serious accidents and death.
	Use all of the described parts in this manual. Ignoring this will make it unsafe to use the product and is highly dangerous.
	Make sure you tighten all of the screws and nuts with the correct torque. Otherwise it is not safe and the mechanical stability and reliability is not given. This is may result in accidents and death.
	Note: Please check the delivery for completeness and damage immediately after you receive the shipment. Please contact your vendor in case of missing or damaged parts.
	Complete installation instructions are available online by following the QR Code on the side, the direct link www.manuals.exactsolutions.de or on our homepage www.exactsolutions.de . They must always be handed over to the person who is carrying out the installation. Read these instructions carefully.

Part List

Part	Quantity
EP1.0 - Outer Frame	2
EP1.0 - Connecting Bar	1
Projector Plate	1
Screw ISO 7380FL - M5x30 - black	6
Screw ISO 7380FL - M5x40 - black	6
Nut DIN 6927 - M5 - black	12
Screw ISO 7380 10.9 - M6x16	6
Schnorr-Washer d=6mm	6



	© COPYRIGHT EXACT SOLUTIONS This print and the information shown thereon, is the property of EXACT SOLUTIONS. It may not be delivered to others nor reproduced for general circulation without the written consent of the EXACT SOLUTIONS.		Material:	Revision: 03			
				Weight: 6,5 kg			
	Date	Name	Title: Assembly instructions for ECO-FRAME-EP1.0				
	Author	12.09.2025 VIU/LVN					
Checked							
	Approved		Part Nr.: ECO-FRAME-EP1.0				
 Dimensions in mm		SCALE: 1 : 10					
		A3					
Status	Change log	Date	Name	Design and specifications subject to change without notice		Number of pages: 1/2	

654321

ECO FRAME EP1.0

D
C
B
A

6x

EP1.0 - Outer Frame

EP1.0 - Connecting Bar


Projector Plate




EP1.0 - Outer Frame

Always place the nut on the inside!

Always place the nut on the inside!

Tighten M5 screws with a torque of 5-7 Nm



				<p>© COPYRIGHT EXACT SOLUTIONS</p> <p>This print and the information shown thereon, is the property of EXACT SOLUTIONS. It may not be delivered to others nor reproduced for general circulation without the written consent of the EXACT SOLUTIONS.</p>			Material:		Revision: 03	
									Weight: 6,5 kg	
					Date	Name	Title: Assembly instructions for ECO-FRAME-EP1.0			
				Author	12.09.2025	VIU/LVN				
				Checked						
				Approved						
							Part Nr.: ECO-FRAME-EP1.0			
							SCALE: 1 : 4 A3			
				  Dimensions in mm						
Status	Change log	Date	Name	Design and specifications subject to change without notice			Number of pages: 2/2			

D
C
B
A